


Hydraulic pivot

Glass door kit


Unscaled format




Installation guide JK81203

Glass cut



Tools necessary






Speed adjustment valve



N°2 - Closing speed

N°2 - Brake speed



Adjust the door's alignment on base.
Check and lock the six adjusting screws, to guarantee
the good positioning and its function

